


MYTEK DIGITAL.USA



MASTERING DIGITAL TO ANALOG CONVERTER

USER MANUAL

VER.5/jan 2006

Use ver.7 manual for newer units (with toslink)

This manual may be updated
Download the newest version at:
Http://www.mytekdigital.com

For technical support, technical tips and support check:
Http://www.mytekdigital.com/products/stereo96dac.htm

or contact Mytek tech support at:
info2007@mytekdigital.com

or at:

tel. (646)-613 1822
fax.(212)-202 5331


Mytek
211 Centre Street
New York NY 10013
USA

Quick Start.....	3
Introduction.....	4
Operation- Internal jumper and trimpots.....	5
Operation- Typical setup -Balanced Output.....	7
Operation- Analog output alignment.....	8
Operation- Unbalanced Output.....	9
Rack mount shelf.....	11
Companion Stereo96 ADC.....	12
Specifications.....	13
Warranty conditions.....	14

Quick Start

Output volume knob sets the output volume with range from mute to max. This is factory default. The knob can be disabled with internal jumpers. Additionally internal precision 10 turn trimpots can be used to set the overall gain of the output. Refer to "Internal jumper settings" for details.

Sample rate selection. Sets the desired sample rate. When used with external clock select FS closest matching that of supplied external wordclock.




When converter is synced to input its behaviour is similar to real world situation with some but not full immunity to jitter. Superlock Mode uses stable internal clock and provides the best clock stability (10ps) and thus the best conversion. In Superlock(tm) mode any signal is upsampled to full 24 bit, 192k resolution and subsequently converted to analog. The two modes are provided for comparison reasons ie. real world vs. ideal sound with no jitter.

Peak meter in -dBFS. The red LED marked "0" corresponds to 1 sample overload.

Hi-Fidelity, high drive headphone out can drive any type of headphones with ultimate fidelity. It's able to provide up to 1 Amp of instant current drive. The headphone out is the same as XLR and it's always routed through the knob.

Line power is 115VAC/50/60Hz (factory default) or 230VAC/50/60Hz switchable by internal switch accessible after removing the top cover. 1 Amp slow blow 20mm fuse is also accessible under the cover.

Analog outputs are +4dB balanced and can be used to drive consumer unbalanced. Leave pin 3 floating for unbl. and if necessary turn down output gain using internal trimpots.



AES/EBU and SPDIF inputs are seamlessly switchable on the front panel, this switch can be used as input selector for 2 sources. They operate in "single wire" mode for all sampling frequencies. Inputs would accept signal up to 96k (external sync) and up to 192k in jitter free Superlock(tm) mode.

Analog outputs are +4dB balanced. They can also be used to drive unbalanced inputs (pin 1 GND, pin 2 signal, pin 3 NC). If the signal is too hot for consumer unbalanced input, turn down the gain using internal precision gain trimpots.

Introduction to Stereo96 Series Converters

The MYTEK Stereo96 series consists of two 1/3 rack units- the Stereo96 ADC and the Stereo 96 DAC. They are also a part of extended family of 1/3 rack units which also includes Stereo192 converters, SRC and Studio Clock. Stereo96 converters can be used as stand-alone devices for variety of studio applications such as mastering, recording and playback, whenever the highest quality conversion is required.

Users choose Mytek converters primarily for their outstanding sound quality. The sound of Mytek converters can be described as "transparent". We design our converters to be as faithful to the signal as possible, rather than follow philosophy of some other manufacturers who offer "analog" or "tube" sounding converters. Mytek converters are closest to a straight wire, which is especially evident when used at full 24/96 resolution. Sonically they are equal or better than the most expensive mastering converters. Even when used in 16 bit mode, the Stereo96 converters produce 20dB (10 times) less distortion than typical converters found in budget recording equipment. On Mytek website you can find and download various sound samples to evaluate Stereo96 series sound quality and compare it to the sound of other high end converter units. To download samples log onto:

http://www.mytekdigital.com/compare/listening_tests.htm

Stereo96 DAC features include:

- 2-channel, 24bit, PCM 192-kHz D-to-A conversion in SuperLock(tm) mode (96-kHz D-to-A conversion in input sync mode when digital input sync is used)
- All sample rates playback with 100-kHz analog bandwidth in SuperLock(tm) mode
- THD+N = -107 dB (0.0005%)
- 120 dB Dynamic Range A-weighted
- AES/EBU and S/PDIF hi speed digital inputs (25-200kHz)
- Digital input source-selection switch
- Balanced, +4dB outputs (+29 dBu) with adjustable gain trimpots
- Unbalanced operation with consumer levels
- Variable or preset output level controls, switch selectable with high-performance conductive plastic attenuator
- Direct connection to powered monitors, the built in attenuator can be used as volume control
- Built-in 0.5A high current drive, hi-speed headphone amplifier
- Total jitter immunity via Superlock™ technology

Stereo96DAC internal trimpots and jumper assignments (remove top cover to access)

Stereo96DAC internal trimpots and jumper assignments (remove top cover to access)


Internal analog output jumpers:

JP2, JP4 - insert front stereo potentiometer as the output XLR volume control- default- used typically when power amp or powered speakers are connected to output. Turn it down for unbalanced consumer -10dBV sources.

JP1, JP3 - overall signal gain- turn it down for unbalanced consumer -10dBV sources- use sinewave alignment procedure described further if necessary.

Internal input gain trimpots:

Overall L/R signal gain- turn it down for unbalanced consumer -10dBV sources- use sinewave alignment procedure described further if necessary. Default is typical +4dB output level.



Typical Setup -Balanced Output

Stereo96 ADC is equipped with 2 XLR analog outputs. For best signal to noise performance it is recommended the signal destination has a typical kOhm impedance (1-20kOhm) input with standard +4dB line level balanced signal. Alternatively a more sensitive unbalanced signal destination can be used as described in subsequent paragraph.

In typical setup the DAC is running on its internal clock in Superlock (tm) mode. In this mode Mytek DAC serves as a very stable low jitter clock source which enables TOTAL jitter immunity which means that any jitter at the DAC digital in is completely removed. In this mode all digital input formats sound exactly the same with no jitter distortion due to jittery source, jittery CD or long input cables. Because of careful design this clock is as good or better than dedicated studio clock generators.

Additionally in Superlock(tm) mode signal of any format (any FS, 16, 20 or 24 bit) is upsampled to 192k/24 bit resulting in overall more realistic and accurate sound. When synced to "digital input" the DAC works as a typical CD Player DAC where jitter is attenuated but its effects can be heard. This second mode is provided for comparison purposes- it allows mastering engineer to assess how the program will sound when played by consumers on their typical DACs.

Setup for typical balanced operation includes following steps:

1. Setup internal jumpers to desired mode of knob operation. Setup all other connections. Set sync to Superlock(tm). Alternatively for testing purposed set sync to external.
2. Select desired signal source. Solid selector led at given input means proper input lock. If input led is flashing there is either no signal or a problem with locking to it. The DAC will automatically sync to any frequency btwn 32-96k (external sync) or 32-192k (Superlock(tm))
3. Play the program- you should be seeing level on the meters as well as hearing the signal at output XLRs and headphones. Turn up the volume knob if necessary. If levels at your power amp are inadequate for the volume knob position- change the out alignment using trimpots.

Analog Output Alignment

1. Turn the output pot all the way up or disable it.
2. Play a digital audio source (DAW generator, test CD etc.) set to approx. 1kHz at the peak operating level you have chosen (let's say you have chosen -18dB).
2. Send the signal from the analog output to the console VU meter. If you don't have a VU meter you can use an AC voltmeter set to measure AC RMS values. "0 VU"at + 4dB corresponds to 1.225 Volts RMS measured between pin hot (2) and pin cold (3) at the output XLRs.
3. Using a tweaker or a small screwdriver adjust the analog output trimpots until the VU meter reads "0 VU".The alignment has to be performed with accuracy of 0.1dB to be considered accurate.

Similar alignment procedure with 0.1dB accuracy is required for valid A/B listening comparisons btwn. different pieces of equipment. A slightly louder source is typically perceived as "better" sounding.

Output driving unbalanced destination

Stereo96 ADC is equipped with 2 XLR analog outputs. For best signal to noise performance it is recommended the signal destination has a typical kOhm impedance (1-20kOhm) input with standard +4dB line level balanced signal. It might be desirable to use a superior sounding amplifier equipped with unbalanced ins to an inferior one which has balanced inputs. The DAC can drive unbalanced inputs as easily as balanced ones. Pin 2 of out XLR should be feeding “signal” of the RCA, pin “1” should be connected to “shield” and pin “3” should be disconnected. If ready made XLR to RCA adapter is used, make sure pin 3 is disconnected inside (typically it’s shorted to gnd). Additionally, since typical unbalanced input is more sensitive at -10dBV, it might be necessary to lower the output gain using internal trimpots (see “alignment”).

Typically the DAC is ran on its internal clock in Superclock (tm) mode. In this mode Mytek DAC serves as a very stable low jitter clock source which enables TOTAL jitter immunity which means that any jitter at the DAC digital in is completely removed. In this mode all digital input formats sound exactly the same with no jitter distortion due to jittery source, jittery CD or long input cables. Because of careful design this clock is as good or better than dedicated studio clock generators.

Additionally in Superclock(tm) mode signal of any format (any FS, 16, 20 or 24 bit) is upsampled to 192k/24 bit resulting in overall more realistic and accurate sound. When synced to “digital input” the DAC works as a typical CD Player DAC where jitter is attenuated but its effects can be heard. This second mode is provided for comparison purposes- it allows mastering engineer to assess how the program will sound when played by consumers on their typical DACs.


Setup for typical balanced operation includes following steps:

1. Setup internal jumpers to desired mode of knob operation. Setup all other connections. Set sync to Superlock(tm). Alternatively for testing purposed set sync to external.
2. Select desired signal source. Solid selector led at given input means proper input lock. If input led is flashing there is either no signal or a problem with locking to it. The DAC will automatically sync to any frequency btwn 32-96k (external sync) or 32-192k (Superlock(tm))

3. Play the program- you should be seeing level on the meters as well as hearing the signal at output XLRs and headphones. Turn up the volume knob if necessary. If levels at your power amp are inadequate for the volume knob position- change the out alignment using trimpots.

Rack Mount Shelf

The Stereo96 ADC is 1/3 rack space wide and 1U tall. Mytek provides a 1U rack mount shelf as accessory to mount up to 3 of 1/3 rack units. The units are attached to shelf with small screw connecting the shelf to bottom through a threaded hole on the bottom of the unit.



Companion Stereo96 DAC

this page will be updated

Specifications

Conversion:	2-channel, 24bit, PCM 192-kHz D-to-A conversion in SuperLock(tm) mode (96-kHz D-to-A conversion in input sync mode when digital input sync is used)
	All sample rates playback with 100-kHz analog bandwidth in SuperLock(tm) mode
Resolution:	24 bit (16-24 bit input accepted)
Dynamic Range:	120dB A-weighted, 117dB Total
THD+Noise:	-107dB (<0.0005%)
Internal clock jitter:	<10picoseconds
Analog Outputs:	+4dBm balanced or unbalanced , 75 Ohm, trimpots and potentiometer for level control. For variable or preset output level controls, switch selectable with high performance conductive plastic attenuator (for direct conn. to power amp or speaker)
Digital Inputs:	Hi-speed (25-200kHz) AES/EBU, SPDIF, Digital input source-selection switch
Jitter	<10psec Total jitter immunity via Superlock™ technology
Headphone Amp	Hi End, High Current Class AB Amplifier
Mains:	100/115V-220/240V 50/60Hz switchable
Dimensions:	1/3 rack space wide x 1U high x 8” deep (5.5”x 1.6”x 8”)
Weight:	4 pounds

Warranty

This Stereo96DAC digital audio converter is warranted by Mytek to the original purchaser against defects in workmanship and materials used in manufacture for a period of one year from the date of purchase. Faults due to customer misuse, unauthorized modifications or accidents are not covered by this warranty.

No other warranty is expressed or implied. Any faulty unit should be sent, shipping prepaid, to the manufacturer service center. Prior to shipping the client should obtain from Mytek an RMA# for warranty services. Units sent without RMA# will not be accepted.

Mytek extends affordable repair service for all units manufactured to date that are not covered by this Warranty.